


PORTABLE LP GAS GRIDDLES

Let your rental center professionals help you select the portable LP gas griddle that is perfect for your event.

Operating Tips

1. Attach a 14.1 oz. or 16.4 oz. disposable propane cylinder to the regulator by sliding upward into the regulator inlet. Carefully engage the threads by pushing the cylinder straight up and turning. Tighten hand tight only. DO NOT use any kind of tools.
2. Remove griddle, open the gas valve 3 or 4 turns and light all four corners of the burner. Place griddle on unit in high heat position (closest to burner).
3. Lift griddle to reduce temperature after warmup or during cooking.
4. DO NOT attempt to adjust flame by turning the shutoff valve; flame is not adjustable.
5. Turn the gas shut off valve as indicated until sealed and flame extinguished to turn the unit off.
6. TURN THE SHUT OFF VALVE OFF WHEN REPLACING AN EMPTY CYLINDER.
7. Frost accumulation on the propane cylinder is normal (no malfunction).
8. Use a non-stick cooking spray on griddle surface prior to cooking for best results.
9. Use a basting syringe to empty grease trough when necessary during cooking.
10. Use only plastic or wood utensils on teflon-coated griddles.
11. DO NOT wet griddle or immerse in water while hot.



Cleaning Tips

1. Clean teflon-coated griddles with water, mild detergent and plastic/cloth pads.
2. Remove stains with vinegar or coffee pot stain removers.
3. Clean uncoated griddles with fine steel wool scouring pads.

Safety Tips

1. Use extreme caution when handling and using propane gas. Escaping gas can result in explosion or fire. (Gas is heavier than air, and will settle in the fire box or on floors.)
2. Permit ONLY competent persons to operate griddles.
3. DO NOT leave griddle unattended.
4. Be sure all corners of each burner are lit; check periodically.
5. Shut off gas valve immediately if flame goes out; allow gas to dissipate for several minutes prior to re-lighting.
6. DO NOT use adapters to connect units to a larger refillable cylinder.
7. DO NOT operate griddle in confined space without adequate ventilation; use a fan if necessary to exhaust air.

Consult your rental center for additional equipment and accessories for your event.



Quantum Party Rentals
419 58th Street
Charleston, WV 25304
304.727.2104
info@quantumpartyrentals.com

UNDERSTAND YOUR RENTAL CONTRACT KNOW YOUR RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED

These guidelines and tips are common-sense suggestions designed to promote portable LP gas griddle efficiency and safety. Compiled from literature of leading experts in the field, they are believed to be reliable, and are offered as suggestions and illustrations to deal principally with common practices and conditions encountered in the use of portable LP gas griddles. The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplant or replace other additional precautionary measures to cover usual or unusual conditions or situations where common sense might otherwise dictate. Accordingly, the American Rental Association and its member firms disclaim all liability for, and make no warranty or guarantee of, the accuracy or applicability of this information in any situation.



american rental association © 1993